

NAMZ “Plug-n-Play” Throttle-by-Wire Harness Kit
Part Number: NTBW-4201

1. BE SAFE, DISCONNECT THE BATTERY FIRST!
2. Our Throttle-by-Wire harness comes ready to install. It is intended for 2008 FL models only.
3. Before you remove your OEM handlebars, disconnect the green connector attached to the twist grip assembly.
4. Now that the twist grip harness is disconnected, trace the wire into your faring (Glides) or headlight nacelle (Road King) until you find the black 6-position Molex connector.
5. Once located, you can now disconnect the throttle-by-wire harness from the main harness.
6. It is recommended to route the NEW throttle-by-wire harness into your new handlebars before they are mounted on the motorcycle.
7. Once the bars are installed, connect the new harness to the twist grip assembly and install twist grip into the handlebar.
8. Lastly, connect the new harness at the 6-position Molex connector to the main harness.
9. Reconnect the battery and test accordingly.